

HRS-TT COVER INSTALLATION GUIDE

Gloved Installation

1. Place the center piece, HRS-TT-Body, on the Tie Top insulator
2. Press down, one side at a time, on top of the omega shape clips located on each end of the center cover to engage the conductor
3. Place the first HRS-Extension arm on the conductor by overlapping its female end on the male end of center piece
4. Press down, one at a time, on top of the omega shape clips located on each end of the extension arm to engage the conductor
5. Place second HRS-Extension on the other male end of the center piece and repeat step 4
6. **Optional:** For additional security, insert the 6 pins provided in the holes located in the omega shaped clips in each section



Hot Stick Installation

1. Engage the hot stick with the hot stick-able loop located in the middle of the center cover piece
2. Place the center piece on the Tie Top insulator and release the hot stick from the loop
3. Tap down with the hot stick next to the loop on each end of the center piece to engage the conductor
4. Place the first HRS-Extension arm on the conductor by overlapping its female end on the male end of center piece
5. Tap down with the hot stick next to the loop on each end of the extension arm to engage the conductor
6. Place second HRS-Extension on the other male end of the center piece and repeat step 5
7. **Optional:** For additional security, Insert the 6 pins provided in the holes located in the omega shaped clips at each section

NOTE: Additional extension arms can be installed to the other arms to increase linear coverage of the bare conductor